



DIVINO THE ONE

Install & User Guide

- EN** **Installation and usage instruction**
Divino The One - Wine Cooler www.indelwebastomarine.com
- I** **Istruzioni per l'installazione e l'uso**
Divino The One - Raffrescatore di Vino www.indelwebastomarine.com
- DE** **Installations- und Wartungsanleitung**
Divino The One - Weinkühler www.indelwebastomarine.com
- FR** **Instructions pour l'installation et l'utilisation**
Divino The One - Rafrâchisseur de vin www.indelwebastomarine.com
- ES** **Instrucciones para la instalación y el uso**
Divino The One - Enfriador de Vino www.indelwebastomarine.com
- NL** **Aanwijzingen voor gebruik en installatie**
Divino The One - Wijnkoeler www.indelwebastomarine.com
- FI** **Asennus- ja käyttöohjeet**
Divino The One - Viinijäähdytin www.indelwebastomarine.com
- SV** **Installations- och bruksanvisning**
Divino The One - Vinkylare www.indelwebastomarine.com
- RU** **Инструкция по установке и эксплуатации**
Divino The One - Охладитель для вина www.indelwebastomarine.com





isotherm

HOW TO ENJOY YOUR DIVINO THE ONE

Serve wine or champagne at the perfect temperature

Its exclusive dry cooling technology creates an envelope of cold and dry air around the bottle, keeping your wine at the best serving temperature.


LOVE EVERY SIP

Your drink will be perfectly chilled, from the first glass to the last.



TOUCH & SERVE

- ON** Tap any part of the Crown with your finger. The light will turn on and within seconds Your The One will be cold and ready for a chilled bottle.
- OFF** Hold your finger on the Crown until the light turns off. This should take 2 seconds.



CHOOSE YOUR COLOUR

Once on, tap 3 times on the Crown. After the flash, **keep tapping** to browse through the colours. Once you find the one you like, simply stop tapping to set the colour. To change colour, repeat this process.



MODE SELECTION

Divino The One is provided with 2 modes: White Wine and Red Wine. Your The One will always start in White Wine mode. To switch, hold your finger on the Crown and release when the light changes to your desired mode:

MODE	TEMP
Off ●	
Red Wine ●	12 - 18°C
Divino The One ○	5 - 18°C



Once you've changed mode, the colour will always return to your chosen colour.

To **check which mode you're in**, tap once on the Crown. The flash of colour will let you know what mode your Divino The One is in.



Indel Webasto Marine S.R.L.
I-47863 Novafeltria (RN) Italy
Telephone: + 39 0541 848030
Email: info@indelwebastomarine.com

www.indelwebastomarine.com



DIVINO THE ONE **ALTERNATIVE CLAMP**




Kind customer,

It may happen, in some product batches, to find a different clamp inside the box from the one indicated in the manual.

Such a clamp is equivalent to the original, although its attachment system is not screw-type but mechanical. In that case, following the installation guide in the manual, just open the clamp, attach and screw it firmly onto the body of the Divino The One.

For any information, please contact:
service@indelwebastomarine.com

Your Isotherm team



DIVINO THE ONE
ADDITIONAL INSTALLATION



Installation - Attaching the Crown

The Base Unit & Crown come separately.

1. Align & lower the Base Unit into specified hole

- 1.1 Carefully lift Divino The One from the box using two hands and lower slowly into hole
- 1.2 Push down evenly to secure the unit in place
- 1.3 There is a black circular seal on the base unit top, don't remove this

2. Attach Crown

- 2.1 Locate the Crown onto the Divino The One and push down evenly
- 2.2 Remove the protective film from the Crown

Important:

Always ensure the Crown is attached before plugging into mains power socket.

If the Crown is removed, turn off from mains power.
Place Crown back on, wait 15 seconds, then turn on at the mains power to ensure recalibration of touch sensitivity.



Index

1. Inside the box/ Scope of delivery	8
2. Introduction of Divino The One	9
3. Symbols used in the manual	10
4. General instructions	11
4.1 Activate - Stand by	13
4.2 Lighting colour selection	14
4.3 Operating environment	14
4.4 Cleaning	14
5. Identification label	15
6. General safety requirements	16
7. Environment	18
8. Design allowances	19
8.1 Minimum allowances	19
8.2 Hole specification	20
9. Ventilation	21
9.1 Vented installation	22
10. Installation	23
11. Electrical connections	24
11.1 Size of the electrical cables	25
12. Technical data	25
13. Warranty	26

User Manual

This manual contains warnings to signal dangers to the user or particular behaviour to comply with; these warnings are indicated as follows:




This manual must be kept for future reference. We recommend that users:

- **Store this manual in an accessible location protected from moisture and heat and protected from the direct rays of the sun.**
- **Use the manual in such a way as to avoid damaging it or any part of its content: do not remove, alter or tear on any part of the manual.**

Despite the care and thoroughness with which this manual has been prepared, Indel Webasto Marine S.r.l. cannot guarantee that the information within covers every possible event associated with installation of the product. Contact our technicians in the event of uncertainty.

In the event of selling or transferring the unit to another person, this manual and related documents should be delivered intact to the new user.

1 Inside the box / Scope of delivery



1. Divino The One
2. Clamp
3. Divino The One Cap
4. This Guide

2 Introduction to Divino The One

Divino The One is a 12V integrated wine cooler that keeps wine or champagne perfectly chilled during service once you've opened the bottle. For bottle storage or cooling, please refer to Isotherm Divino 23 and 35.

Take a cold bottle from the fridge, put it in your The One and tap the crown to activate the device. The One will keep your wine or champagne within 1-2°C of opening temperatures whilst you drink it.

No drips, no mess and no maintenance. Just perfectly chilled wine.

It will make your wine tasting easy and fun!

Its exclusive dry cooling technology creates an envelope of cold and dry air around the bottle, keeping your wine at the best serving temperature.

Your drink will be perfectly chilled, from the first glass to the last.

3 Symbols used in the manual

Summary of signs

<p>Obligation to read instructions The presence of this symbol mandates reading of instructions before putting the unit into operation.</p>	
<p>Obligation to disconnect The presence of this symbol mandates immediate disconnection of the unit from the mains in case of failures.</p>	
<p>Obligation to wear gloves The presence of this symbol mandates each operator wear suitable protective gloves.</p>	
<p>Obligation to wear shoes The presence of this symbol mandates each operator wear shoes designed to decrease the risk of injury</p>	
<p>General hazard The presence of this symbol mandates special attention by the operator.</p>	
<p>Shock Hazard The presence of this symbol tells personnel involved that the described operation may present a risk of electric shock.</p>	
<p>General prohibition The presence of this symbol represents a prohibition applicable to various situations.</p>	

User Manual

4 General instructions

 **WARNING!**  Do not start the product before reading this instruction manual.

 **WARNING!**   Always use PPE (Personal Protective Equipment) during product handling and installation.

 **WARNING!** - Any changes made to the product without the knowledge of the manufacturer will be the sole responsibility of those carrying out said changes. Changes made without the permission of Indel Webasto Marine S.r.l. will void all warranties and may void the declaration of conformity to applicable directives.

 **WARNING!** - Any use of the Divino The One differing from that described in this manual is prohibited.

 **WARNING!** - Indel Webasto Marine S.r.l. disclaims all liability for any malfunction or damage to persons or property due to improper use of the machine or with materials with different characteristics than those described in this manual.

 **WARNING!** – Do not place live animals inside the refrigerator.

 **WARNING!** – Never open the cooling circuit for any reason.

 **WARNING!** - The appliance must be protected against indirect contact in accordance with the “Heavy current regulations”.

 **WARNING!** - Divino The One must never be used as a support.

 **WARNING!** - Do not use the unit in a manner different from that foreseen.

 **WARNING!** - Do not store explosives or flammable aerosols inside the unit or near the refrigerator unit. Aerosols containing such substances can be identified by the flame symbol or other indications shown upon the product’s label.

 **WARNING!** - The product must be installed in an area accessible for any maintenance. The installation area must however be protected by removable panels or guards and not directly accessible.

User Manual

4.1 Activate - Standby

Simply touch any part of the crown to activate the device.

Your The One will be at temperature within seconds, and ready for a chilled bottle.

Once activated, it will stay chilled for 2 hours, then go into standby mode. Should you wish to use it for longer, simply touch the crown during use to restart its 2 hour cycle.

It can be manually put into standby mode, to do this touch the crown for 2 seconds.



4.2 Lighting colour selection

The smart featured crown allows you to change the illumination mode.

Tap the crown 3 times, then scroll through the colours by touching the crown repeatedly.

To lock in a colour, do not touch the crown for 5 seconds.

4.3 Operating Environment

A well ventilated, dry, and screened by environments (water, sun, salt...) application is strongly recommended thus necessary for a correct use and performance of the device.

4.4 Cleaning

When cleaning the crown, use a soft cloth that will not scratch the mirror-polished finish. This is valid for the chamber as well.

If The One is used for long periods of time, or in humid ambient temperatures, frost or water condensation can develop in the chamber.

This is normal and it will eventually evaporate.

If needed, clean with a soft cloth.

User Manual

5 Identification label

The identifying data of the Divino The One are contained on the label placed on the side of the product.

Exact citing of the model, serial number and year of manufacture facilitate rapid and precise response in the event of need for technical support from trained Indel Webasto Marine S.r.l. service network technicians. Below an example of label.

 <p>mod. DIVINO THE ONE cod. 7N01TG9UP0000 SN. XXXXXXXXX</p> <p>Climatic Class: N 12V \Rightarrow 7A 75W</p>	<p>Indel Webasto Marine Srl S. Agata Feltria (RN) 47866 Italy</p> <p>www.indelwebastomarine.com</p> <p>Made in UK   </p>
--	---



WARNING! - Do not remove affixed labels, as these must be stored secured fastened, maintained intact and in good condition for readability.

To avoid having to go to read data each time on the identification label, we recommend taking note of the most important data in the below table:

Model code:
Serial Number S/N:

6 General safety requirements

The following safety rules concern the care to be given by the user for proper use of the product:

 **WARNING!** - Never touch any damaged or non-insulated electrical cables while the electrical power supply is enabled.

 **WARNING!** - Disconnect the appliance from the mains power supply immediately in the event of any malfunction. Contact qualified personnel or the Service Centre.

 It is **FORBIDDEN** to tamper with or modify the unit's refrigerant circuit and electrical circuit.

 **WARNING!** - Install the unit in a dry place that's sheltered against water spray.

 **WARNING!** - Do not install the unit near heat sources, such as stoves, boilers, radiators etc.

 **WARNING!** - Any repairs to be performed upon the unit's refrigerant circuit should be entrusted to qualified personnel.

 **WARNING!** - If there is a battery charger, it must be connected to the battery and never directly to the unit.

 **WARNING!** - The Divino The One must be connected downstream of a power supply system equipped with cut-off devices (switches) which permit total disconnection of the unit current and

User Manual

protective devices which automatically intervene in the event of malfunction.

 **WARNING!** - Verify that the power supply system is equipped with a differential circuit breaker for current leakage.

 **WARNING!** - The electrical plug must be accessible after installation. The appliance must always be enclosed and not accessible without the use of a tool. The unit installation area must be made with a material resistant to the needle-flame test required by standard EN 60335---1 or else be more than 5 cm from electrical and/or electronic components.

 **WARNING!** - Ensure that the unit is sufficiently ventilated.

 **WARNING!** The unit can not be used by children under 8 year of age.

The unit can be used by children older than 8 years of age and by people with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, provided they are supervised or after they have received instructions on safe use of and understanding of the dangers inherent in it.

Children should not play with the unit. Cleaning and maintenance meant to be performed by the user and must not be performed by unsupervised children.

7 Environment

This product complies with the Directive 2012/19/EU WEEE regarding waste electrical and electronic equipment (WEEE).

The product's proper disposal is essential to preventing negative consequences for the environment and human health.



The symbol  on the product, the packaging and/or the accompanying documentation indicates that the product should not be disposed of as household waste. The product must be taken to an authorized collection centre for the recycling of electrical and electronic equipment. The product must be disposed of in compliance with the current local environmental regulations regarding waste disposal.

For more information regarding the disposal, recycling and reuse of the product, please contact your local authorities, your local waste collection service or the retailer/company from whom the product was purchased.

The packaging, which has been designed to protect the unit and its components during transport, is manufactured from recyclable material. The packaging bears the recycling symbols and must be disposed of at an appropriate collection centre.



The symbol  indicates that the product complies with all European Union provisions provided for its use.

User Manual


8 Design Allowances

Integrating Divino The One on board is incredibly easy. All you need is the specification of a hole, a power supply and ventilation.

8.1 Minimum allowances

Ensure that the void has a minimum internal height of 420mm and the hole is at least 73mm away from the internal walls.


If installing multiple The Ones into one void, ensure that the centre points of each hole are 200mm apart.



8.2 Hole specification

A 155mm hole can be created using:

- CNC / water jet cutting
- A standard 152mm hole saw



Achieve the perfect on board installation and the greatest performances as follows:

1. Install in a dry suitable place, screened from water splash, chlorinated water, sun, salt and heat coming from other devices.
2. Ventilation: minimum ventilation requirements must be respected.
3. Power supply: 12V DC. (Installed power, cable section, recommended fuse).

 **WARNING!** - During installation, provide a minimum distance from flammable parts. This distance should not be less than 5 cm.

 **WARNING!** After installation, check to make sure that all the unit's live parts, as well as its condensing unit, can only be accessed voluntarily by removing the panels or other protection systems.

9 Ventilation

A small vent is required when Divino The One is installed into a void with a volume smaller than 0,11m³.

Installation consideration:



- Ensure The One is not installed in close proximity to appliances that generate heat;

- Ensure the base and sides of The One are not obstructed;
- Ensure the base and sides of The One are not located in an area where they are vulnerable to damage or obstruction.

9.1 Vented installation

Voids that are less than $0,11\text{m}^3$ require a small vent into another void or into ambient air to allow for better airflow circulation.

The vent should have an area of at least 9000mm^2 and is usually best placed in the back panel.




Pease bear in mind, when studying the ventilation, to respect the basic principles: air intake at the bottom of the installation area and air exhaust at the top.


In case a unique venting grid is feasible, performances of the device can be enhanced by avoiding air short cycling as per the picture. In this case, a vertical grid is recommended.

User Manual

More venting grids



Unique venting grid




10 Installation

Carefully lift the Divino The One from the box using hands and lower slowly into hole.

Carefully press down evenly on top until flush with the countertop, then locate the Crown onto Divino The One and push down evenly, removing any protective film.

Screw the clamp on until it is fastened tightly against the underside of the countertop.



⚠ WARNING!

When positioning the appliance, ensure the power supply cord is not trapped or damaged.

11 Electrical connections

Connection to the electrical mains can be made for Divino The One operation.

An even better solution is installing a transformer, an optional accessory, which switches automatically from battery power to electrical power when the latter is connected.

- Before turning on the appliance, check to make sure that the voltage of the electrical system and/or battery complies with that which is indicated on the unit's data plate.
- Connect the refrigerator directly to the battery or to the relative main switch and make sure that the system is equipped with an electric device that's capable of protecting the circuit against possible overcurrents.
- If the power supply voltage is different from 12Vdc, install a Δ 0.03A differential circuit breaker. Avoid connecting the unit via the vehicle's control panel as this could result in voltage drops.
- Insert a fuse upstream from the refrigerator (see the table below). Connect the red wire to the electrical system's positive terminal, and connect the black wire the negative terminal. Use a pressed lug terminal that's suitable for the cable's size.
- A separate switch that simultaneously disconnects the power cables must be installed upstream from the refrigerator. Check to make sure that the installed switch supports the corresponding load indicated in the table below.

Model	12Vdc
Divino The One	15A

⚠ WARNING! If there is a battery charger, it must be connected to the battery and never directly to the refrigerator.

11.1 Size of the electrical cables

Always use cables of a suitable cross-section. The minimum cross-sections are listed in the table below:

Cross-section in mm ²	AWG Section	Max 12 V cable length m/ft
2.5	13	2.5/8
4	11	4/13
6	9	6/19
10	7	10/33

12 Technical data

- The One input voltage : 12 Vdc
- Max power usage: 75 Watts
- Max 12Vdc Amps: 7 Amps
- Auto switch off: 2 hours without reactivation
- Ambient temp. limit: 10° to 32°C / 50° to 90°F

13 Warranty

The Indel Webasto Marine warranty complies with EU Directive 1999/44/EC.

Validity period

The warranty for Isotherm Divino The One is valid for 3 years with regard to the cost of labour for repair or replacement, but only if carried out by IWM network, and therefore authorised, service centres.

The validity period starts from:

- a) The date of sale indicated on the product invoice or sales receipt
- b) The date of the invoice or registration document of the first sale of the boat in which it is installed, if installed by the manufacturer of the vehicle
- c) In the absence of one of the above documents, the week of production

indicated in the S/N (serial number)

Replacement of a product or component does not change the validity period.

The warranty covers:

- Replacement or repair of the product or of one or more components acknowledged to be faulty due to manufacturing defects.
- Breakage or malfunction of components under warranty validity despite proven proper installation and proper use.
- Labour and transport according to the operating methods described below.
- Costs for shipping the replacement product (not including charges for customs clearance).

The warranty does not cover defects, damage or malfunctions caused by:

- Negligence, neglect or improper use
- Incorrect installation or incautious handling
- Insufficient ventilation

User Manual

- Incorrect electrical connection
- Undersized wiring
- Improper maintenance or maintenance performed by unauthorised personnel
- Failure to follow the instructions contained in this manual
- Transport damage
- Charges for customs clearance
- Items subject to wear, fuses etc.
- Professional use
- Damage caused by weathering

Essential information for determining whether the case is covered by the warranty:

- Product code (indicated on the product label)
- S/N (serial number) (indicated on the product label)
- Invoice or sales receipt (or possibly registration document, see above in Validity period section)
- Detailed description of the defect (Attach photos if possible)
- Description of installation with particular attention to ventilation and wiring (Attach photos if possible)

(If it is determined that the case is not covered under warranty, the customer must pay all expenses for repairs, replacements, labour, travel of persons and transport. IWM is not required to bear any expense.)

Operating procedures to be applied once it is ascertained that the case is covered by warranty:

Divino The One installed on boats:

Warranty repairs must be performed exclusively by service centres (CAT) that are part of the Indel Webasto Marine network. IWM does not cover costs for service performed by others. Find the service centre nearest to you at www.indelwebastomarine.com

For products installed on boats, an IWM authorised CAT technician will come to the boat if it is located at a distance of maximum 100km from the CAT. IWM shall cover the cost of this transfer. If the boat is over 100km away, the customer can choose whether to pay the cost of the technician's transfer (in this case paying the technician directly), or to move the boat closer.

IWM does not reimburse any expense for spare parts purchased elsewhere, not of the IWM network.

Divino The One installed on Recreational vehicles (RV):

Warranty repairs must be performed exclusively by service centres that are part of the Webasto network.

The vehicle must be brought to the service centre.

Find the service centre nearest to you at www.webasto.com